

TABLE 4-5a
Shape and depth factors for use in either the Hansen (1970) or Vesic (1973, 1975b) bearing-capacity equations of Table 4-1. Use s'_c , d'_c when $\phi = 0$ only for Hansen equations. Subscripts H , V for Hansen, Vesic, respectively.

Shape factors	Depth factors
$s'_{c(H)} = 0.2 \frac{B'}{L'}$ ($\phi = 0^\circ$)	$d'_c = 0.4k$ ($\phi = 0^\circ$)
$s_{c(H)} = 1.0 + \frac{N_q}{N_c} \cdot \frac{B'}{L'}$	$d_c = 1.0 + 0.4k$
$s_{c(V)} = 1.0 + \frac{N_q}{N_c} \cdot \frac{B}{L}$	$k = D/B$ for $D/B \leq 1$
$s_c = 1.0$ for strip	$k = \tan^{-1}(D/B)$ for $D/B > 1$
$s_{q(H)} = 1.0 + \frac{B'}{L'} \sin \phi$	$d_q = 1 + 2 \tan \phi (1 - \sin \phi)^2 k$
$s_{q(V)} = 1.0 + \frac{B}{L} \tan \phi$	k defined above
for all ϕ	
$s_{\gamma(H)} = 1.0 - 0.4 \frac{B'}{L'}$	$d_\gamma = 1.00$ for all ϕ
$s_{\gamma(V)} = 1.0 - 0.4 \frac{B}{L}$	

Notes:

1. Note use of "effective" base dimensions B' , L' by Hansen but not by Vesic.
2. The values above are consistent with either a vertical load or a vertical load accompanied by a horizontal load H_B .
3. With a vertical load and a load H_L (and either $H_B = 0$ or $H_B > 0$) you may have to compute two sets of shape s_i and d_i as $s_{i,B}$, $s_{i,L}$ and $d_{i,B}$, $d_{i,L}$. For i , L subscripts of Eq. (4-2), presented in Sec. 4-6, use ratio L'/B' or D/L .

TABLE 4-5b
Table of inclination, ground, and base factors for the Hansen (1970) equations. See Table 4-5c for equivalent Vesic equations.

Inclination factors	Ground factors (base on slope)
$i'_c = 0.5 - \sqrt{1 - \frac{H_i}{A_f C_a}}$	$g'_c = \frac{\beta^\circ}{147^\circ}$
$i_c = i_q - \frac{1 - i_q}{N_q - 1}$	$g_c = 1.0 - \frac{\beta^\circ}{147^\circ}$
$i_q = \left[1 - \frac{0.5H_i}{V + A_f C_a \cot \phi} \right]^{\alpha_1}$	$g_q = g_\gamma = (1 - 0.5 \tan \beta)^\gamma$
$2 \leq \alpha_1 \leq 5$	
Base factors (tilted base)	
$i_\gamma = \left[1 - \frac{0.7H_i}{V + A_f C_a \cot \phi} \right]^{\alpha_2}$	$b'_c = \frac{\eta^\circ}{147^\circ}$ ($\phi = 0$)
$i_\gamma = \left[1 - \frac{(0.7 - \eta^\circ/450^\circ)H_i}{V + A_f C_a \cot \phi} \right]^{\alpha_2}$	$b_c = 1 - \frac{\eta^\circ}{147^\circ}$ ($\phi > 0$)
$2 \leq \alpha_2 \leq 5$	$b_q = \exp(-2\eta \tan \phi)$
	$b_\gamma = \exp(-2.7\eta \tan \phi)$
	η in radians

Notes:

1. Use H_i as either H_B or H_L , or both if $H_L > 0$.
2. Hansen (1970) did not give an i_c for $\phi > 0$. The value above is from Hansen (1961) and also used by Vesic.
3. Variable c_a = base adhesion, on the order of 0.6 to $1.0 \times$ base cohesion.
4. Refer to sketch for identification of angles η and β , footing depth D , location of H_i (parallel and at top of base slab; usually also produces eccentricity). Especially note V = force normal to base and is not the resultant R from combining V and H_i .